

PS 30 PLUS BRISAČ ZA POVRŠINSKI ČISTAČ

Moćna četka za ribanje PS 30 Plus uklanja uporne mrlje pomoću tri mlaznice visokog pritiska. Zahvaljujući obrtnoj bočnoj mlaznici s lakoćom se čiste svi uglovi i ivice.




Kataloški br.

2.644-212.0

Tehnički podaci


4054278713311

Boja		crna
Težina	kg	0,9
Težina sa ambalažom	kg	1,3
Dimenzije (D x Š x V)	mm	749 x 264 x 768




Zaokretna bočna mlaznica

- Savršeno čišćenje svih uglova i ivica bez prskanja.



Glava četke može da se okreće 360°

- Za punu fleksibilnost na teško dostupnim mestima.



Prsten sa čekinjama (takođe i na bočnoj mlaznici)

- Zaštita od prskanja vode, bez obzira na podešavanje mlaznice.

KOMPATIBILNI UREĐAJI

- G 7.180
- K 2 Battery
- K 2 Classic
- K 2 Universal Edition
- K 3 Classic
- K 3 Power Control
- K 4 Classic
- K 4 Power Control Flex
- K 4 Power Control Flex Car & Home
- K 4 Power Control Flex Home
- K 4 Power Control Home
- K 4 WCM
- K 5 Classic
- K 5 Power Control Flex
- K 5 Power Control Flex Car & Home
- K 5 Power Control Flex Home
- K 5 Power Control Home
- K 5 Smart Control Flex
- K 5 WCM
- K 7 Power Flex
- K 7 Power Flex Home
- K 7 Smart Control Flex
- K 7 Smart Control Flex Home
- K 7 WCM
- K2 Battery Set
- K2 Power Control
- K2 Power Control Home
- K2 Premium Power Control
- K3 Power Control Home
- K3 Premium Power Control
- K4 Power Control
- K4 Premium Power Control
- K4 Premium Power Control Home
- K5 Power Control
- K5 Premium Smart Control
- K5 Premium Smart Control Home
- K7 Premium Smart Control
- K7 Premium Smart Control Home
- K7 Smart Control
- K7 Smart Control Home